




OPERATION MANUAL

COMPLEX FOR PAINTING TBS-3D.COMPLEX



Content

1. General	4
1.1. Signs and symbols	4
1.2. Safety instructions	5
1.3. Intended use	5
1.4. Nameplate	6
1.5. Technical specifications	7
2. Preparations for installation	9
2.1. Necessary tools	9
2.2. Personal protective equipment	9
2.3. Completeness of the equipment	9
3. Installation	10
3.1. Preliminary instructions	10
3.2. Location of the booth	10
4. Adjustment and connection	11
4.1. Electrical connection	11
5. Operation of the booth	25
5.1. Functioning principle and operation	25
5.2. Operating conditions	26
6. Maintenance	26
6.1. Equipment cleaning, cleaning/replacement of filters	26
6.2. Regular condition monitoring	28
6.3. Regular maintenance	28
6.4. Mounting/dismounting the blower impeller	28
6.5. Dismounting the blower impeller support	29
6.6. Cleaning the impeller	29



6.7. Filter elements29

6.8. Unscheduled maintenance.....30

7. Other provisions33

7.1 Checks33

7.2 Troubleshooting tips34

7.3 Possible blower failures – troubleshooting34

7.4 Warranty conditions.....35

7.5 Safety instructions37

7.6 Transportation, packing and storage37

8. Notes38

9. Annexes40

1. General

1.1. Signs and symbols



Warning sign: CAUTION! Important safety notices related to personnel safety. Strictly follow these instructions.



Protective gloves. Use protective gloves to avoid cut injuries caused by contact with sharp edges



Protective clothing. Wear protective suit to avoid personal injuries during performance of the assembly works



Footwear. Use safety footwear to protect your feet from heavy weights, which may fall during performance of the assembly works



Personal protective equipment – respiratory and eye protection equipment

1.2. Safety instructions

Persons performing installation, operation and maintenance of the unit shall read and understand this Installation and Operation Manual, and observe the requirements it contains.

Connection and initial commissioning of the unit shall only be performed by qualified persons or under supervision of such personnel. Take into consideration regulations and standards related to installation works as well as the workplace safety rules. Use personal protective equipment when performing any works with the painting booth or its units.

Always disconnect the booth and all its electrical assembly units from the mains before starting any repair works.

1.3. Intended use

TBS painting booth is a professional solution for organization of the painting section in the woodworking, furniture and metalworking industries. The primary task of such booth is to create excess pressure in internal space of the booth and to distribute air flow between painting and drying zones.

The painting zone is equipped with the TBS booth, air supply unit with a water coil air heater provided for maintenance of the desired temperature (in the range from 5 °C to 20 °C) and plenum boxes for uniform distribution of the air flow. The air supply unit creates excess pressure to ensure the minimum possible dust content in the painting zone, thus significantly improving product quality.

It should be mentioned that TBS painting booth is designed in compliance with the requirements of State building codes (DBN), which ensures operational efficiency and safety of the painter:

- Absence of draughts allows preventing cold-related illnesses of the personnel.
- Increase in production performance due to process organization when the painter does not need to take breaks for breathing “fresh air” outdoors.

The air supply unit in the drying zone and suction columns maintain the required temperature and create horizontal air flow, allowing for uniform drying of the painted parts.

1.4. Nameplate

The nameplate attached to the equipment in a clearly visible location contains identification data of the booth.

Identification nameplate:

- Series and model
- Data of manufacture
- Serial number


	07402, Ukraine, Brovary, Kyiv Region Str. Nezalezhnosti Boulevard, 53 Tel. (+38044)586-59-86 info@aton-service.com.ua www.aton-service.com.ua	
	Model:	<input type="text"/>
	Data of manufacture:	<input type="text"/>
	Serial number:	<input type="text"/>

	07402 , Ukraine,Brovary, Kyiv Region Str.Nezalezhnosti Boulevard, 53 tel. (+38 044) 586-59-86 info@aton-service.com.ua www.aton-service.com.ua	
	TYPE : XXXXXXXX	
	NR.: XXX-XXX/XX-XX	
	V: 400	PH: 3
	HZ: 50	
KW: XX.X		A: X.X
Year of construction:		20xx
		

1.5. Technical specifications

Specifications and characteristics of TBS-3D.COMPLEX produced and delivered by Aton Service LLC are given in the table below:

Parameter	TBS-3D.COMPLEX
Capacity by removed air, m ³ /h	9000
Total pressure, Pa	1300/630
Power, kW	8.25
A, mm	3080
B, mm	2000
H, mm	2240
Heating capacity, kW	45
Heat transfer fluid temperature, °C	80/60
Air temperature, °C	5/20
Blower	RL-AS 500/4/2.2 kW
Filter type	Corrugated board (labyrinth) filter PaintStop type
Filter size, mm	900 1000
Number of filters	3
Tunnel extension module	1
Drying zone, m ²	> 24
Automatic control station	CP TBS professional
Ductwork, set	1



2. Preparations for installation

2.1. Necessary tools

A set of tools necessary for installation of the booth: power nut driver with a set of jets (or a set of socket heads with ratchet wrench), sealant gun, a set of open end wrenches, ladder.



2.2. Personal protective equipment



Protective gloves. Use protective gloves to avoid cut injuries caused by contact with sharp edges.



Protective clothing. Wear protective suit to avoid personal injuries during performance of the assembly works.



Footwear. Use safety footwear to protect your feet from heavy weights, which may fall during performance of the assembly works.

2.3. Completeness of the equipment

Before starting assembly and installation works, make sure that all necessary parts and components are available by checking the equipment against the delivery list.

Depending on air delivery rate, the booth may consist of the following main parts:

- Paint booth TBS-3D;
- Tunnel extension module;

- Air-preparation unit, including pre-filtration and heating;
- Supply blower;
- Plenum boxes;
- Adjustable air dampers;
- Control panel.

All component elements of the booth are listed in the shipment checklist (either for standard or for extended delivery package). Standard scope of delivery includes only equipment initially offered by the manufacturer, and extended scope of delivery additionally includes options requested by the customer.

3. Installation

3.1. Preliminary instructions

- Installation of the booth equipment shall be carried out by qualified personnel in compliance with safety rules and taking into account instructions of the manufacturer's engineer.
- Use drawings and specifications to facilitate the installation process.
- Refer to the connection diagram for details on power supply connection to the control panel

3.2. Location of the booth

- Location of the unit on-site shall ensure easy connection of power supply to the control panel.
- The supporting floor surface shall be plane and shall have sufficient strength to take loads from the booth.
- It is necessary to ensure free space of at least 1 m at each side of the booth for maintenance purposes.
- Do not install the equipment close to sources of open flame or highly flammable substances.
- Electrical safety of this equipment is only achieved in case of proper connection to the grounding system (in accordance with the electrical safety standards).

4. Adjustment and connection

4.1. Electrical connection

WARNING: After turning off the booth and after alarm reset, the booth equipment continues working until the end of the operating cycle. For safe performance of works on the equipment, deenergize the equipment by opening circuit breakers (input switch) and take measures (lockout-tagout) to prevent its accidental re-energizing in accordance with the Rules for Safe Operation of Electrical Installations of Consumers (DNAOP).



CAUTION! Ground the control panel and metal parts of the booth after connection of the power supply.

This operation manual for the control cabinet of the ventilation system is intended for engineers and technicians who perform its installation, adjustment and operation.

The control cabinet is designed for operation of the ventilation system and is built based on Freemax MX S2 controller. The controller allows the operator to set the required air temperature, monitor system conditions and identify alarm events.

The control cabinet performs the following functions:

- supply air temperature regulation
- controlling system modules
- protection of the equipment

Brief description of the control system

- control cabinet.
- supply blower 1.
- exhaust blower 1.
- exhaust blower 2.
- heat transfer fluid (HTF) circulation pump.
- three-way valve.

When the system is started in Winter mode, the water coil air heater warms-up until the set HTF return temperature (which depends on the outside air temperature) is reached. Air damper of the supply unit opens only upon expiry of the preset holding time.

During operation of the system, the controller regulates the supply air temperature by means of the three-way valve.

The supply and exhaust blowers always work simultaneously, and are both controlled by the controller.


HTF circulation pump is permanently running in Winter mode, and is permanently off in Summer mode.







Caution!







It is forbidden to de-energize the control cabinet or to cut off circulation of HTF through the water coil air heater when the system is running in Winter mode. Failure to comply with this instruction may result in damage to the heater.


Fire alarm signal

When fire alarm signal becomes active, all blowers are stopped.




H4	 <p>A rectangular black frame containing a white label at the top with the text "B1 blower running" and a large green circle below it.</p>	Indicator light – exhaust blower B1 of the paint booth is running
H7	 <p>A rectangular black frame containing a white label at the top with the text "B2 blower running" and a large green circle below it.</p>	Indicator light – exhaust blower B2 of the drying zone is running
H5	 <p>A rectangular black frame containing a white label at the top with the text "HTF circ. pump running" and a large green circle below it.</p>	Indicator light – HTF circulation pump is running
H6	 <p>A rectangular black frame containing a white label at the top with the text "System fault" and a large red circle below it.</p>	Indicator light – system fault
H8	 <p>A rectangular black frame containing a white label at the top with the text "Fault of the supply blower" and a large red circle below it.</p>	Indicator light – fault of the supply blower drive Fault removal actions – close QF1 motor circuit breaker
H9	 <p>A rectangular black frame containing a white label at the top with the text "Fault of B1 blower" and a large red circle below it.</p>	Indicator light – drive fault of exhaust blower B1. Fault removal actions – close QF2 motor circuit breaker

H1		<p>Indicator light – drive fault of exhaust blower B2. Fault removal actions – close QF4 motor circuit breaker</p>
H10		<p>Indicator light – fault of the HTF pump drive. Fault removal actions – close QF3 motor circuit breaker</p>
H16		<p>Indicator light – Fire alarm</p>
H2		<p>Indicator light – indication of the power-system fault status</p>
H12		<p>Indicator light – filter of the supply unit is clogged</p>
H15		<p>Indicator light – filter of the exhaust booth wall is clogged</p>



Indicator light – supply plenum box filter of the paint booth is clogged



Indicator light –supply plenum box filter of the drying zone is clogged

List of electrical components:

Q1 – main switch.

F1 – 24 V control circuits.

QF1 – circuit breaker of supply blower П1.

QF2 – circuit breaker of exhaust blower B1.

QF3 – circuit breaker of the paint booth HTF circulation pump.

QF4 -- circuit breaker of exhaust blower B2 of the drying zone.

QF5 – 380 V control circuit.

T1 – transformer 220/24 V 50 VA.

PKΦ – phase control relay.

K1, K2 – electromagnetic relay.

Freemax MX S2 controller



The controller has 6 control keys:





- | | |
|-------|--|
| Esc | <ul style="list-style-type: none"> • Return to the parent window. • Cancel changes made for the parameter being edited. |
| Enter | <ul style="list-style-type: none"> • Switch to subwindow. • Enter parameter editing mode. • Save new value for the parameter being edited. |
| ← | <ul style="list-style-type: none"> • Navigate through windows to the left (if the focus mode is not active). • Navigate through parameters in the current window to the left (if the focus mode is active). • Decrease value of the parameter being edited. |
| → | <ul style="list-style-type: none"> • Navigate through windows to the right (if the focus mode is not active). • Navigate through parameters in the current window to the right (if the focus mode is active). • Increase value of the parameter being edited. |
| F1 | Turn cursor on/off. |
| F2 | Switch between the service menu and parameter windows. |

Accessing menu functions

The controller menu is formed by multilevel windows that contain various variable data

Navigating through windows

The controller offers two navigation modes – navigation with active or non-active focus (cursor). You can turn the focus on and off by pressing **F1** key. The focus mode is on if any of the menu elements is boxed (enclosed in frame).

If the input focus is not active, arrow keys   are used to navigate between windows in the current level. If the input focus is active, arrow keys   are used to navigate (in a cyclic manner) between elements of the current window.



When the focus mode is active, navigation between some windows is performed by selecting certain items of the current window – activation of such items moves you to another window.

When the focus is active and positioned on any window element, pressing **ENTER** key moves you from the parent window to subwindow or activates the parameter editing mode. Pressing **ESC** key returns you back from subwindow to the parent window.

Accessing service menus

Service menu (i.e. service engineer's menu) of the controller contains date and time settings, as well as the firmware loading option. Press **F2** key to enter the service menu. Pressing the **F2** key again will bring you back to the window that was active before calling the service menu.

Changing parameters

Changing any parameter setting is performed with active focus. Place the input focus onto the desired parameter value and press **ENTER**. The parameter value starts flashing. Then use arrow keys   to set a new value. Press **ENTER** to confirm new parameter setting or **ESC** to cancel changes. The parameter value stops flashing.

Entering password

In order to restrict user access to configuration settings, some parameters are password protected.

If a parameter or access to certain subwindow is password protected, the controller will display the password input field.

Main screen			
Heat ctrl		T warm-up	42.6
valve	28.4	T fr.dang.	22.7
		Warm-up	120
		Damper	40
Pump Off		T set	20
Supp. blower Off		T out	5.2
Ex. blower Off		T supp	20.2
		T ret.water	25.4
		T supp.water	30.8

Heat ctrl valve – heat control valve opening percentage (100% – opened).

Pump – state of the HTF circulation pump (Off – stopped, On – running).

Supp. blower – state of supply blower (Off – stopped, On – running).

Ex. blower – state of exhaust wall blower 1 (Off – stopped, On – running).

T warm-up – warm-up temperature. Warm-up is considered to be successful upon expiry of the warm-up period the HTF return temperature is higher than T warm-up.

T fr.dang. – temperature of freeze-up danger. Return water temperature at which the danger of water coil freezing during system operation arises.

Warm-up – warm up time or countdown timer during warming up.

Damper – damper opening time or countdown for damper opening.

T set – preset supply air temperature. Position the input focus onto the parameter value and set the desired temperature.

T out – indication of the external air temperature.

T supp. – indication of the supply air temperature.

T ret.w – indication of return HTF temperature.

T supp.water – indication of supply HTF temperature.

Warm-up mode

If **T out** is below 2 °C, warming-up is performed during the entire warming-up time, and the damper begins to open after **T ret** reaches **T ret.warm-up**.

If **T out** is above 2 °C, warming-up is performed during **Min. warm-up time**, and warming-up is stopped when **Tret** reaches **Tret.warm-up**. In any case, the damper begins to open as soon as the warming-up starts.

During warming-up the heat control valve stays 100% open.

Water coil air heater		
Warm-up time	120	
Min. warm-up time	70	
Winter/Summer mode	1	Winter
Tallow warm-up	15	
Air supply damper opening time		40
Tret. Chart		

Warm-up time – heat exchanger warming-up time when the system is started in Winter mode.


Min. warm-up time – minimum heat exchanger warming-up time when the system is started in Winter mode.

Winter/Summer mode – set the desired operating mode (1 – Winter, 0 – Summer). Indication of the current operating mode. Summer mode cannot be activated if the outside temperature is below 2 °C. If Winter mode is activated, it is necessary to feed hot water to the heat exchanger inlet.

T allow warm-up – set the limiting value when warming-up is allowed. If outside temperature is higher than the T allow warm-up, warming-up at system start-up will not be performed.

Air supply damper opening time – opening time for the damper of the of the air supply unit.

Tret.chart – open “Tret. Chart” window.

Alarms		
Water freeze dang.	0	0
Underheating	0	0
Pump failure	0	
Flow switch	0	
Supp. blower failure	0	
Ex. blower failure	0	
Phase control	0	
Sensor failure	0	

Water freeze dang. – 0 – normal operation, 1 – danger of water coil freezing acc. to readings of the HTF return temperature sensor. Current number of the alarm events (on the right).

Underheating – 0 – normal operation, 1 – underheating of the water coil air heater (upon expiry of the warm-up period, HTF return temperature has not reached the set value (see “**Tret. Chart**” window)). Current number of the alarm events (on the right).

Pump failure – indication of the HTF circulation pump alarm (0 – normal operation, 1 – alarm). Alarm – tripping of the pump motor current protection device.

Flow switch – indication of the flow switch alarm (0 – normal operation, 1 – alarm) acknowledge signal from the flow switch (if installed) is not available.

Supp. blower failure – indication of the supply blower alarm (0 – normal operation, 1 – alarm). Alarm – tripping of the supply blower motor current protection device.

Ex. blower failure – indication of the exhaust blower 1 alarm (0 – normal operation, 1 – alarm). Alarm – tripping of the exhaust blower motor current protection device.

Phase control – power-system fault. Check if all phases are available, check phase sequence and voltage.

Sensor failure – failure of one of the temperature sensors (0 – normal operation, 1 – alarm).



Alarm reset button.

Alarms

Active alarm causes stop of the system, inactive alarms are only displayed in the menu screen. To turn on the system after alarm, it is necessary to select the active alarm and press the “Reset alarm” button.

Number of alarms
Underheating 2 Water freeze danger 3

Underheating – number of underheating events that resulted in generation of alarm signal.

Water freeze danger – number of water coil freezing danger events acc. to signal of the return HTF temperature sensor.

Status of sensors
Out sensor – OK
Supp. air sensor – open circuit
HTF ret. sensor – short circuit
Correction of sensors

Out sensor – OK – status of the external air temperature sensor.

Supp. air sensor – open circuit – status of the supply air temperature sensor.

HTF ret. sensor – short circuit – status of the return HTF temperature sensor.

Correction of sensors – open temperature sensors correction window.

Heat control valve	
Min. travel limit	25
Max. travel limit	100
Control laws	
Number of alarms	

Min. travel limit – set the minimum travel limit for the heat control valve (%)

Max. travel limit -- set the maximum travel limit for the heat control valve (%)

Control laws – open “Control laws” window

Number of alarms – open “Number of alarms” window

Control laws	
PID regulator	
Kp	2
Ti	80
Zone	0.5

Kp – proportional gain factor.

Ti – integration time (s).

Zone – dead band (°C).

Tret. Chart			
	Tout1 -22	Tout2 2	Tout3 15
Tret. set	40	30	20
Tret. prog	50	45	35
Tret. dang.	40	20	10

The below protection functions are active only in Winter mode.

Tout – temperature of the external air.

Tret. set – HTF return temperature that will be maintained when the blowers are off.

Tret.prog. – HTF return temperature. The system will be started if upon expiry of the warm-up period HTF return temperature is higher than Tret.prog.

Tret.dang. – HTF return temperature. If during operation HTF return temperature drops below Tret.dang., “Danger” alarm signal is generated and the system is stopped.

Correction of sensors	
Out air sensor	0
Supp. air sensor	0
HTF ret. sensor	0
HTF supp. sensor	0

Out air sensor – correction of the external air temperature sensor.

Supp. air sensor – correction of supply air temperature sensor.

HTF ret. sensor – correction of the return HTF temperature sensor.

HTF supp. sensor – correction of the supply HTF temperature sensor.

Window tree

Main screen		
Heat ctrl	T warm-up	42.6
valve 28.4	T fr.dang.	22.7
	Warm-up	120
	Damper	40
Pump Off	T set	20
Supp. fan Off	T out	5.2
Ex. fan Off	T supp	20.2
	T ret.water	25.4
	T supp.water	30.8

Water coil air heater	
Warm-up time	120
Min. warm-up time	70
Winter/Summer mode	1 Winter
Tenable warm-up	15
Air supply damper opening time	40
Tret. Chart	

Alarms		
Water freeze dang.	0	0
Underheating	0	0
Pump failure	0	
Flow switch	0	
Supp. fan failure	0	
Ex. fan failure	0	
Phase control	0	
Sensor failure	0	

Tret. Chart			
	Tout1 -22	Tout2 2	Tout3 15
Tret. set	40	30	20
Tret. set	50	45	35
Tret. dang.	40	20	10

Heat control valve	
Min. travel limit	25
Max. travel limit	100
Control laws	
Number of alarms	

Status of sensors	
Out sensor – OK	
Supp. air sensor – open circuit	
HTF ret. sensor – short circuit	
Correction of sensors	

Control laws	
PID regulator	
Kp	2
Ti	80
Zone	0.5

Number of alarms	
Underheating	2
Water freeze risk	3

Correction of sensors	
Out air sensor	0
Supp. air sensor	0
HTF ret. sensor	0
HTF supp. sensor	0

5. Operation of the booth

5.1. Functioning principle and operation

Working zone – air of the working zone is cleaned from harmful contaminating particles that are formed during paintworks of woodworking, furniture and metalworking industries. The blower draws the contaminated air into the painting booth. Major part of harmful particles formed during paintworks is retained in the system of successive filters, which are mounted inside the stand. Filtered air is discharged to the outside.

Drying zone – allows organizing drying of painted parts by maintaining the required temperature and creating horizontal air flow in the room, which contributes to establishing advantageous drying conditions for the paint coatings.

The drying zone includes:

- Plenum box for distribution of clean air;
- Suction columns placed at the corners of the zone for extraction of paint vapours and creation of horizontal air flow;
- MB-AS series exhaust blower.

Air supply unit with water coil air heater in the drying zone maintains the required temperature (in the range from 5 °C to 20 °C). It is also equipped with plenum boxes for uniform distribution of the air flow. The unit creates excess pressure to ensure the minimum possible dust content in the painting zone, thus significantly improving product quality.

The air supply unit in the drying zone and suction columns maintain the required temperature and create horizontal air flow, allowing for uniform drying of the painted parts.

The booth is turned on by pressing the green button on the control panel.

The booth is turned off by pressing the red button on the control panel.

5.2. Operating conditions

This unit is designed and manufactured to handle any air mixtures.

The booth shall not be used for treatment of air that contains large and long fractions of sawdust, cloth, foreign metal inclusions or any other materials that can damage the blower, filters and the booth.

Do not remove filter elements. It is only allowed to remove filter elements for maintenance or repair purposes and only when the control panel is deenergized. Do not perform any interventions when the booth is in operation.

6. Maintenance



CAUTION! Any maintenance works shall be performed when the equipment is disconnected from power supply

6.1. Equipment cleaning, cleaning/replacement of filters

Follow the below procedure to carry out cleaning of the equipment:


- Cut off power supply to the equipment by turning the main switch to OFF position and wait until the blower comes to a complete standstill;
- To replace the cardboard filter, unscrew wingnuts (8 pcs.), then remove the retaining plates of the filter (4 pcs.), after which you can replace the used cardboard filter with a new one.
- To replace PaintStop filter, unscrew wingnuts (12 pcs.), and then remove the filter cassette cap (3 pcs.). The filters are now accessible and can be replaced.

Always use personal protective equipment when performing the above operations.



CAUTION! Keep any ignition sources (cigarettes, flames, sparks) away when performing cleaning operations.





6.2. Regular condition monitoring

Regular condition monitoring of the booth and its filter elements is of critical importance for ensuring adequate safety level and prevention of explosion and fire risk, which may be attributed to deposition and accumulation of highly flammable particles inside the filtering unit. When moving, the accumulated highly flammable dust particles create potentially explosive dust cloud, so such dust deposits and accumulations shall be minimized. The dust deposits can also ignite due to exposure to hot surfaces, sparks and flame.

6.3. Regular maintenance

Every 600 hours of operation:

- Listen for noise from the rotating motor parts, impeller, and bearings.

Every 1200 hours of operation:

- Check bolt connections for tightness.

Every 2400 hours of operation:

- Test blower impeller assemblies for balancing.

Every 1600 hours of operation:

- Clean and lubricate bearings, replace if necessary.

Every 180 hours of operation:

- Remove and clean the filter elements, replace if necessary.

Every 160 hours of operation:

- Air purging of the main air ducts: open all dampers, start the blower for a few minutes (do not perform any operations on the unit during air purging).

6.4. Mounting/dismounting the blower impeller

- Unscrew mounting bolts and nuts and dismount the blower.
- Remove the inlet nozzle of the blower.
- Remove the fixing screw and washer used to attach the impeller to the shaft.
- Take off the impeller using a puller tool. In doing so, place a spacer between the impeller support and the shaft to prevent the shaft from being damaged.
- Assemble the blower in the reverse order.

6.5. Dismounting the blower impeller support

- Dismount the impeller as described above.
- Unbolt the support by removing the fixing bolts and change, if necessary, internal parts of the support and the bearings.
- Assemble the support in the reverse order.

6.6. Cleaning the impeller

The impeller shall be statically and dynamically balanced to prevent vibration. Regularly check the impeller for cleanliness. Oil vapours, resins, air humidity and other factors contribute to the adhesion of dust, grease and other materials to the impeller surfaces, which leads to its disbalancing and results in damage to the motor and the blower case. The symptoms are increased noise and vibration.

To clean the impeller, first check if the motor is disconnected from the electric power supply. All cleaning actions shall be carried out through the inspection door of the blower. Clean the impeller with a brush. Make sure to remove all contaminating materials during cleaning, as any remains can result in disbalance.

Aton Service LLC declines any responsibility for damages to the motor, blower case and impeller itself due to accumulation of foreign materials on the impeller.

6.7. Filter elements

- Damage of the filter fabric results in passage of unfiltered air through the filter.
- Average operating life of a filter element makes 12 to 24 months provided that the filter element is used properly and is protected from ingress of moisture and foreign objects that can damage the filter fabric.
- Replacement and installation of filter elements is described in section 6.1.

6.8. Unscheduled maintenance

If unscheduled maintenance is required due to visual or hearing defects that occurred during operation of the booth, it is recommended to assign a person responsible for maintenance of the blower. The defect/failure and its exact cause shall be detected and recorded in the Unscheduled Maintenance Report. If a defect/failure occurs during the warranty period, contact the manufacturer for repair. If a defect/failure occurs after the manufacturer's warranty expires, and if you are not able to locate or remedy the problem by yourself, contact the manufacturer's personnel for advice.

Filter types used in the painting booth:

- Cardboard filter:

SepaPaint ink mist separation filters (sometimes referred to as "labyrinth" filters) for paint-spraying cabins constitute the first filtering stage for the air extracted from the painting zone. These filters are made of pleated multilayer filtering material with process holes for the passage of air. Particle-loaded air flow has to change its direction several times due to the labyrinth filter construction. As a result of such air flow arrangement, airborne particles stick to the walls and plating of SepaPaint filter. After passing through the pre-filtration stage, the exhaust air is directed to the mate-type filtering material. Pre-filtration of air extracted from the paint-spraying cabin ensures prolonged operational life for the material of the second filtering stage. Thus, the use of labyrinth filters in paint-spraying cabins helps to cut down costs for the purchase and replacement of more expensive filter materials of fine filtering classes.

- **Temperature of the working environment:** up to 100 °C
- **Fire behaviour classification acc. to DIN 53438:** F1/K1
- **Initial pressure drop (V=0.5 m/s):** 20 Pa
- **Initial pressure drop (V=0.75 m/s):** 40 Pa
- **Initial pressure drop (V=1 m/s):** 70 Pa
- **Recommended final pressure drop:** 130 Pa

- **PaintStop filter:**

PaintStop mate-type floor filtering material for paint-spraying cabins represents the final air filtering stage in rooms where different products are painted by aerosol paints. The filter material is made of unevenly arranged pre-heat-treated fibreglass. These fibres are relatively elastic, and their width gradually increases towards the rear mate side (clean air side). Rear side of the Paint Stop floor filter is reinforced by applying a special layer.

Due to its innovative structure, PaintStop floor filters feature high dust accumulation ability and gradual (not rapid) increase of pressure drop across the filter. These properties allow extending maintenance intervals for the paint booth ventilation system and help to reduce variable costs for replacement of the PaintStop floor filter.

- **Material:** glass fibre
- **Air flow per 1 m²:** 2500-6300 m³/h
- **Initial pressure drop:** 4-12 Pa
- **Final pressure drop:** 80 Pa
- **Arrestance:** 95%
- **Material thickness:** 70 ± 5 mm
- **Unit weight:** 210 ± 30 g/m²

- **Pocket filters for ventilation systems:**

These filters are one of the most widely used in ventilation equipment for separation of dust particles from the supply and recirculated air. Pocket filters are used to prevent clogging of heat exchangers and heat recuperators in air conditioning equipment as well as for treatment of atmospheric air before supplying it to service areas.

Pocket filters for ventilation systems feature relatively long service life owing to their design – the filter material is sewn to form dust collection bags (pockets). Area of the filtering material and depth of pockets vary depending on the filter size. The larger the filtration area and the deeper the pocket, the longer is the service life of a pocket filter.

- **Filter class:** G3, M5, F7, F9
- **Filtering media:** polyester, micro-glass fibre media, meltblown media
- **Final pressure drop:** 200/200/250 Pa
- **Maximum operating temperature:** 90 °C
- **Regeneration:** no

- Ceiling mounted filter for paint-spraying cabins:

These filters prevent dust particles, including dust of the finest fractions, from entering to the painting zone. Here ceiling mounted particulate filters guard against degradation of painting quality, as deposition of dust on the surface to be painted may result in production of low-quality products.

Ceiling mounted filters for paint-spraying cabins serve as the last filtration stage before the supply air enters the working room. Generally, stages of primary filtration by means of pocket filters are either provided as part of the air supply unit, or installed in the supply duct in filter boxes.

Ceiling filters for paint-spraying cabins shall be placed in a damper in a way to completely cover the entire cross section of the air distribution grille. This ensures uniform distribution and filtration of the entire volume of supplied air, as well as long service life of the filtering material.

- **Temperature of the working environment:** $\leq 80\text{ }^{\circ}\text{C}$
- **Humidity of the working environment:** $\leq 100\%$
- **Filter class:** M5
- **Filtering medium:** polyester
- **Fire behaviour classification acc. to DIN 53438:** F1/K1
- **Certification:** Öko-Tex Standard 100
- **Nominal air flow:** $900\text{ m}^3/\text{h}$
- **Air velocity:** 0.25 m/s
- **Initial pressure drop:** $30/35\text{ Pa}$
- **Final pressure drop:** $650/750\text{ Pa}$
- **Average arrestance:** 90%
- **Material thickness:** 25 mm

7. Other provisions

7.1 Checks



CAUTION! The following operations shall be carried out by qualified personnel at disconnected equipment.

Item to be checked	Frequency of maintenance	Works to be performed
Cleaning	Cleaning shall ensure that deposits and accumulations of dust do not remain for more than one working shift	Cleaning of internal and external surfaces
Filtering elements	Once a month	Check
Screws and nuts	After the first 500 hours of operation, then – once a year	Check for tightness
Warning plates	Once every 6 months	Make sure that the plates are legible and undamaged

7.2 Troubleshooting tips



CAUTION! The following operations shall be carried out by qualified personnel at disconnected equipment and only after contacting the equipment Supplier.

PROBLEM	POSSIBLE REASON	REMEDY
The system does not draw in air once it is started	Incorrect blower direction	Check the direction of rotation

7.3 Possible blower failures – troubleshooting

Problem	Possible reason	Remedy
Insufficient air flow	<ul style="list-style-type: none"> ◆ Incorrect direction of rotation ◆ Insufficient speed ◆ Deposit of dirt on the impeller ◆ Dirty filters 	<ul style="list-style-type: none"> • Interchange motor phases • Check supply voltage, reliability of electrical contacts • Clean the impeller • Clean or replace filter elements
Heavy starting	<ul style="list-style-type: none"> ◆ Excessive power consumption ◆ Insufficient motor torque 	<ul style="list-style-type: none"> • Replace the motor • Check motor data against the technical documentation
Power consumption of the blower exceeds the value specified in the technical documentation	<ul style="list-style-type: none"> ◆ Dirty filters ◆ Deposit of dirt on the impeller ◆ Air ducting/air intakes clogged or partially blocked 	<ul style="list-style-type: none"> • Perform cleaning of filters more frequently • Clean the impeller • Clean the air ducting, check position of the air dampers

Elevated noise level	<ul style="list-style-type: none"> ◆ Unbalanced impeller, displaced relative to the housing 	<ul style="list-style-type: none"> • Check for correct installation and condition of the impeller
Excessive vibration	<ul style="list-style-type: none"> ◆ Unbalanced impeller or other rotating parts ◆ Improperly installed or fixed blower 	<ul style="list-style-type: none"> • Cleaning or replacement • It is recommended to install the blower on foundation made of concrete slabs or on a sufficiently rigid frame.

7.4 Warranty conditions

- The warranty period shall make 12 months from the date of signing of the delivery note or Acceptance Act, but shall be limited to 18 months from the moment of dispatch.
- The warranty shall mean Supplier's obligation to provide the Buyer (free of charge for the Buyer) with non-defective part in exchange for the defective one if the defect is due to the manufacturer's fault. At that, the part (assembly unit) shall be replaced in the shortest possible time, but not later than 30 business days from the date of written Buyer's notice informing about the detected defect and based on the act issued by the Supplier's customer service department.
- The Buyer shall request for replacement of a part (assembly unit) in writing only; the request shall contain indication of the equipment model, serial number and description of the defect.
- Assembly (disassembly) of the part shall be carried out by the Buyer. The Buyer may charge the Supplier with performance of this work. At that, terms of work and payment conditions shall be agreed separately.
- The warranty shall become void if the Buyer violates any of the following provisions:
 - the equipment shall be used for its intended purpose or in accordance with the relevant instructions of the Supplier or the manufacturer;
 - regular maintenance of the equipment shall be carried out in accordance with the requirements of the Operation Manual;
 - any modifications to the design and update of the equipment shall be made only upon the Supplier's written consent;

- warranty seals specified in the operational documents remain intact;
- the equipment is operated by persons who have received relevant training and are aware of the operation conditions, allowable and forbidden operating methods, maintenance procedures, safety rules (for example, received training during start-up and adjustment works);
- observance of all transportation, preservation and shipping conditions relating to the equipment;
- observance of operation conditions and connection specifications relating to the equipment (electric power and pneumatic connections) and their conformance to Operation Manual for the equipment;
- use of original spare parts authorized by the manufacturer only;
- compliance with the humidity conditions in premises where the equipment is operated (booth for indoor use).
- The Supplier's warranty shall not cover damages of the equipment caused by force majeure events as well as assembly units and parts subject to natural wear and tear during operation, such as
 - driving belts;
 - rubber blades, plastic parts and woven fabrics;
 - light bulbs, fuses and similar parts;
 - drive screws, drive screw nuts, gear segments, gear wheels.
- Equipment or its components, included to the Buyer's claim (complaint), shall be provided to the Supplier's representative for review and verification within 14 calendar days from their breakdown. Otherwise the part (assembly unit) will be replaced on a paid basis.
- The warranty shall not cover defects caused by the following factors:
 - Unqualified (unskilled) operation or external impacts (e.g. scratches, dents, other deformations);
 - contamination of any origin;
 - repair and any other operations with respect to the equipment performed by technical personnel who has not received training from the Supplier;
 - damages that occurred during transportation of the equipment by the Buyer.
- Requirements contained in the Operation Manual provided by the Supplier to the Buyer shall be mandatory. The Buyer has the right to request in writing an additional copy of the Operation Manual, and the Supplier has the right to provide it in paper or electronic form.
- The Supplier shall neither accept nor consider Buyer's claims for damages related to stoppage or downtime of the equipment.

7.5 Safety instructions

The Buyer shall comply with instructions/requirements contained in this Operation Manual and in fire safety regulations. Particular care shall be paid to cleaning of the internal space of the unit and its external parts to avoid excessive accumulation of highly flammable dust. It is also necessary to prevent any ignition sources (such as live coal, sparks, open flame, cigarettes, or any other sources) from entering into the unit through air intakes.

7.6 Transportation, pacing and storage

- Transportation (if performed by the Buyer). Each item of the equipment shall be checked and tested before shipping. The warranty period starts from the date of delivery and covers workmanship and quality of materials. The shipper shall bear responsibility for any damages that occurred during transportation. Disassembled filtering complex is packed in plastic materials or cardboard. All packing waste shall be disposed of in accordance with the legislation in force. The equipment shall be transported with care to avoid dropping or overturning. Lifting and transportation shall be carried out by appropriate vehicles and lifting machinery. Transportation shall be carried out in accordance with the accident prevention regulations currently in force.
- Unloading. Unloading of the equipment shall be entrusted to professional loaders or to personnel experienced in unloading of this kind of equipment.
 - Do not remove transport fixtures used to lock parts of the equipment during transportation until all the equipment parts are unloaded and located in place.
 - Follow handling instructions and use lifting and load-attaching points marked on the equipment.
- Storage and reallocation (if performed by the Buyer). The equipment shall be protected from atmospheric effects, dust and falling objects that may hit the equipment. In case of long period of time between the delivery and installation dates, it is necessary to perform periodic (weekly) checks of the blower by rotating it manually in order to prevent damage of the bearings. It is not allowed to leave blower impeller at rest for a long period of time. The manufacturer shall not be liable for damages of the equipment caused by prolonged standing period.
- Dimensions and the weight are shown in the technical data specification, section 1.5.

[illegible]



2

